


# Panel-Integrated FOP unit of FURUKAWA



*Standardization for installation and design!*

*Easy design!*

*Various combination!*

*Easy installation!*

## Product Number for FOP unit with fusion splicing unit

FOP  /  / N


1: for 1 connector  
2: for 2 connectors

2U-: 2U size for EIA rack  
3U-: 3U size for EIA rack  
( "3U-" : Omissible )


Connector maker	Connector type	Type Code
LEMO	EDW	LR
LEMO	FXW	LPR
LEMO	FBW	LPRB
TAJIMI	OPS-R	SR
TAJIMI	OPS-PR	SPR
TAJIMI	OPC-R	CR
TAJIMI	OPC-PR	CPR
FISCHER	DBQ1053	FR
FISCHER	DSQ1053	FPR

## Sample of Product Number


3U - FOP1 / LPR / N



2U - FOP2 / LPR / N



3U - FOP2 / LPR + LR



## Product Number for FOP unit with JJ adapter (Not fusion splicing)

FOP  /  / N - JJ

Please refer to above "Product Number for FOP unit with fusion splicing unit"

Please add this code

# Panel-Integrated FOP unit of FURUKAWA


## Product Number for FOP unit for panel flange connector




Please refer to above "Product Number for FOP unit with fusion splicing unit"

Connector maker	Connector type	Type Code
LEMO	FMW	LPP
LEMO	PBW	LPJ
LEMO	PEW	LPJE
TAJIMI	OPS-PP	SPP
TAJIMI	OPS-PJ	SPJ
TAJIMI	OPC-PP	CPP
TAJIMI	OPC-PJ	CPJ
TAJIMI	MPX178-PP	MPX178-PP
TAJIMI	MPX177-PJ	MPX177-PJ
FISCHER	DSBE1053	FPP
FISCHER	DKBE1053	FPJ


### 3U – FOP1 / LPP / N



### 2U – FOP2 / LPP / N




### 3U – FOP2 / LPP + LPJ




## Product Number for FOP unit for special use

### 3U – FOP1 / LR / N – SS




With circuit breaker

### 3U – FOP2 / MPX177 – PJ + SR / N



With Triaxial connector

## Sample of installation with FOP unit



### Headquarters

6-48-10 Higashi-Nippori, Arakawa-ku, Tokyo, 116-0014 Japan  
Tel: 81-3(3803)-1151 Fax: 81-3(3801)-0581  
http: www.feic.co.jp

### American Furukawa, Inc.

47677 Galleon Drive, Plymouth, Michigan USA 48170  
Tel: 01-734-446-2201 Fax: 01-734-446-2260  
http: www.americanfurukawa.com

### Furukawa Electric Europe, Ltd

3rd Floor Newcombe House 43-45 Notting Hill Gate London, W11 3FE UK  
Tel: 44-(0)20-7221-6000 Fax: 44-(0)20-7313-5310  
http: www.furukawa.co.uk

### Furukawa Electric Singapore PTE Ltd

10 Anson Road, #25-07/08 International Plaza, Singapore 079903  
Tel: 65-6224-4686 Fax: 65-6224-2362  
http: www.furukawa.com.sg

※Products listed in this brochure are subject to change without prior notice for improvement of appearance and/or specifications.

#### Export Control Regulations

※The products and/or technical information presented in this publication may be subject to the application of the Foreign Exchange and Foreign Trade Act and other related laws and regulations in Japan.

※In addition, the Export Administration Regulations (EAR) of the United States may be applicable.

※In cases where exporting or reexporting the products and/or technical information presented in this publication, customers are requested to follow the necessary procedures at their own responsibility and cost.

※Please contact the Ministry of Economy, Trade and Industry of Japan or the Department of Commerce of the United States for details about procedures.